Chromecast (Gen 1)

Online directions: goo.gl/x77Js3

Quick Start

1. **Plug in:** Plug Chromecast into your TV, then connect the USB power cable to your Chromecast.

   Next, either plug the other end of the USB power cable into an open USB port on your TV OR into the included power adapter which you will then plug into a power outlet. **Note:** Only use the provided AC adapter.

2. **Download the Google Cast app:** On your mobile device, tablet, or laptop, download the Google Cast app

3. **Set up Chromecast:** Launch the app and follow these simple Chromecast setup instructions (flip page over) or watch the video below to get your device cast ready.

4. **Connect:** Double check that the Chromecast and the mobile device, tablet, or laptop you are using to set up Chromecast with are both on the *same Wi-Fi network*.

5. **Watch:** Cast videos, movies, TV shows, and more from your mobile device, tablet or laptop to your TV.

1

Select your Chromecast. Tap **Set Up**.

2

Check to see that the code on your phone matches the code on your TV. Click **I see the code**.

3

Optional: Change the name of your Chromecast. Select **Set Name**.

Note: Guest mode is automatically enabled at set up. You can uncheck the box to turn the feature off. Learn more about how guest mode works here.

4

Connect your Chromecast to your WiFi network. Click **Set Network**.

These instructions may vary depending on device.

DES PLAINES PUBLIC LIBRARY
1501 Ellinwood Street · Des Plaines, IL 60016